

[review](#)  
[german](#)

## Bootloader Installation - Allgemeine Bemerkungen

Es gibt 2 Optionen für die allererste Bootloader Installation:

- Option 1: Debug adapter. Vorbedingungen:
  - STM „ST-Link/V2“ Adapter,
  - PC mit STM Link SW
- Option 2: STM „Defuse“. Vorbedingungen:
  - PC mit STM Defuse Tool installiert
  - USB-microUSB Kabel (um PC mit OVI40 UI zu verbinden)

Nachfolgende Bootloader upgrades können gemacht werden mit:

- Option 1: ST-Link/V2
- Option 2: DfuSE
- Option 3: USB-Stick. Vorbedingungen:
  - USB stick, FAT oder FAT32 formatiert, mit korrektem Bootloader File
  - Auf dem OVI40 UI installierter UHSDR bootloader, funktioniert

Die neueste Bootloader SW kann [hier](#) gefunden werden. Abhängig von der gewählten Option 1, 2 oder benötigt man:

- \*.bin Date (reines Binary File)
- \*.dfu Datei (Binary File mit zusätzlichen Infos, z.B. Lade-Adresse)

Für eine allererste UHSDR Bootloader Installation muß der Jumper „P6“ gesetzt sein, siehe unten. Für nachfolgende Bootloader Installationen kann der Jumper offen bleiben!

Die nächsten Abschnitte erklären alles detaillierter

## "P6 Jumper" Methode zur allerersten Bootloader Installation

P6 jumper schließen, wenn:

- Noch nie ein UHSDR Bootloader auf diesem OVI40 UI installiert war
- Bootloader nicht funktioniert und andere Installationsmethoden gescheitert sind

Nach Schließen des P6 Jumpers mit Option 1 oder Option 2 fortfahren.

Nach erfolgreichem Upgrade daran denken, den P6 Jumper **wieder zu öffnen**.

## Option 1: ST-Link upgrade

ToDo

## Preconditions

- Download latest bl-40SDR.bin bootloader from [here](#).
- Connect STM ST-Link V2 adapter to PC and to OVI40 UI.
- ST-Link SW installed and running on PC, USB drivers installed, adapter recognized by PC
- OVI40 UI powered up with 5V (JP1)

## Procedure

## Further Reading

- ST-Link V2 user manual
- STM32 ST-Link SW Utility user manual
- [STM ST-Link/V2 USB drivers available here](#)
- [ST-Link SW utility available at bottom of this page](#)

## Option 2: DeFuse Tool upgrade

ToDo

## Preconditions

- Download latest bl-40SDR.dfu bootloader from [here](#).
- Install ST-Micro DeFuse Tool: <http://www.st.com/en/development-tools/stsw-stm32080.html>
- Connect PC with OVI40 UI via USB - to - MiniUSB cable. Use MiniUSB plug on OVI40 UI
- ST-Micro DFuse SW installed on PC and running, USB drivers installed, OVI40 UI recognized by PC
- OVI40 UI powered up with 5V (JP1)

## Procedure

- Boot loader installation described [here](#)

## Further reading

- ST-Micro DFuse Tool description
- [DfuSe Ressources and SW \(bootom of page\)](#)

## Option 3: USB-Stick upgrade upgrade

ToDo

## Preconditions

- Download latest bl-40SDR.bin bootloader from [here](#).
- Format USB-Stick with FAT file partition. Make sure - just in case - that USB-stick is otherwise empty
- Copy .bin file to stick. Make sure it is copied as file, not just a link / short-cut
- OVI40 UI powered up with 5V (Pin 28 JP1) and 8V (Pin 29 JP1) and GND (Pin 30 JP1). The 8V powers the USB stick via voltage regulator
- Recent UHSDR boot loader installed and working

## Procedure

1. Supply +8V on JP1 pin 29 - to power USB stick
2. Push and - important - hold switch „BAND -“
3. Supply +5V on JP1 pin 28 - this starts the boot loader
4. insert USB stick into large USB port of OVI40 UI
5. Wait for FW upload to finish
6. Release switch „Band -“
7. Remove +5V, then apply again to reboot OVI40 UI.

## Check proper working of newly loaded boot loader

Remove Jumper P6 if previously closed, then boot UI.

Check boot loader version number displayed in system menu corresponds to the version you intended to install.

## UHSDR Bootloader further reading

Forum:

- <https://www.amateurfunk-sulingen.de/forum/index.php?board=15;action=display;threadid=551;start=75>
- <https://www.amateurfunk-sulingen.de/forum/index.php?board=15;action=display;threadid=947>
- [mCHF Inbetriebnahme Tipps](#)

Github Wiki:

- <https://github.com/df8oe/UHSDR/wiki/Bootloader-Installation>
- [https://github.com/df8oe/UHSDR/blob/81dd4afae1a52103b2f1824cba34e2ff35e805ea/mchf-eclipse/useful\\_manuals/bootloader\\_doc.md](https://github.com/df8oe/UHSDR/blob/81dd4afae1a52103b2f1824cba34e2ff35e805ea/mchf-eclipse/useful_manuals/bootloader_doc.md)
- <https://github.com/df8oe/UHSDR/wiki/Topics:-UHSDR:-SW-Installation-on-SDR>
- <https://github.com/df8oe/UHSDR/wiki/Firmware-Upgrades>

From:

<https://www.amateurfunk-sulingen.de/wiki/> - **Afu - Wiki des DARC OV Sulingen I40**

Permanent link:

<https://www.amateurfunk-sulingen.de/wiki/doku.php?id=uhsdr:uhsdrbl&rev=1517940177>

Last update: **06.02.2018 18:02**

